

Instructions for using the ceiling mounted LCD projector in this room:

1. BEFORE turning on the laptop or projector, please connect the VGA connector to the laptop
2. Power on the laptop
3. Power on the LCD projector using the small “BENQ” remote control found in this room (point the remote at the front of the projector and press the power button)
4. Wait for the projector to warm up and for the picture to appear
5. If the projector powers on but does not show the computer screen, press the “Source” button on the remote and use the arrow buttons to select Computer #1. For Dell laptops, press Function + F8 to send the video to the projector.
6. To turn off the projector, point the remote control at the projector and press the power button twice.

Please leave the LCD Projector Remote Control in this room!!! Thank you! ☺

--Education IT, edit@purdue.edu, 765-494-2658

LCD Projector Instructions (Continued)

Macintosh Users:

If you see your computer desktop background, but do not see your desktop icons, your computer may have extended your work area across two displays in dual-monitor mode (your main screen + the projector). If this has happened, you may need to go to: System Preferences... → Displays → Arrangement → Check the box to “Mirror Displays”.